

PET DRAGON FUZZ FEATURES AND FUNCTIONS

- 1) INPUT JACK connects to your guitar or pedal output
- 2) FUZZ LEVEL controls the amount of fuzz
- 3) LED INDICATOR is illuminated when the effect is engaged
- 4) OUTPUT LEVEL controls the output level of the effect
- 5) DC JACK connects to a 2.1mm/5.5mm 9VDC Center Negative power supply
- 6) OUTPUT JACK connects to the amplifier input or additional pedals



ZIONSVILLE, IN 46077 http://www.delisleguitar.com

UNIT A